



Diaphragm



MODEL	A	B	C	D	E	F	G
T9-45	127.5	61.2	110	30	8.1	30°	3
T9-50	127.5	68	112	32	8.5	35°	3.5
T12-45	139	79	120	35	8.5	24°	3.2
T12-50	136	79	125	36	8.5	23°	3.5
T14-57	146	82	127	34	8.5	23°	3.5
T14-64	148	80.5	134	48	8.2	20°	3.5
T16-57	157	95	136	40	8.5	16°	3.5
T16-64	158	90	140	41	8	15°	3
T16-76	160	93.5	135	47	9.6	16.5°	3
T20-57	168	102	147	36	8.3	33°	3.4
T20-64	168	102	150	44	8.5	23°	3.2
T20-76	169	94.5	151.6	50	8.3	22°	3
T24-64	180	109	158	42	8.3	15°	3
T24-76	177	103	160	52	8	16.5°	3
T24-64	199	110	170	40	9.5	21°	3
T30-64	199	125	182.5	40	9.4	30°	3.5
T30-76	200	126	183	50	9.5	23°	3.2
T36-76	224	205	158	44	8.6	36°	3

Yoke(KA35YK)



MODEL	PICTURE	DIMENSIONS				
		B	C	D	M	L
T-03	A	14	33	15	M16x1.5	46
T-05	B	12.5	33	14	M16x1.5	47
T-09		12	28.5	15	5/8-18 UNF	45
T-07	C	12	28	14	M16x1.5	43
T-08	D	14	46-112	15	M16x1.5	54-120
T-06	E	14	46	15	M16x1.5	54
D-09	F	12.7(1/2")	57	14	5/8-18 UNF	73

Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer



Air Dryer




Air Dryer




Air Dryer




Air Dryer



Air Dryer



Air Dryer



Air Dryer Seat/Condenser



Air Dryer Cartridge



E1



E2



E3



E4

Silencer



G1



G2



G3



G4



G5

NO.:	KA NO.:	ORIGINAL NO.:	PORTS	COMMENT
------	---------	---------------	-------	---------

Air Dryer Cartridge



F1



F2



F3



F4



F5

Unloader Valve



A1



A2



A3



A4



A5

Unloader Valve



B1



B2



B3




B4



B5

Pressure Limiting Valve



Pressure Limiting Valve



Pressure Limiting Valve



Pressure Limiting Valve



C1



C2



C3



C4

Pressure Limiting Valve



Pressure Limiting Valve



D1



D2




D3



D4


Four Circuit Protection Valve




Four Circuit Protection Valve




Four Circuit Protection Valve



Four Circuit Protection Valve




Four Circuit Protection Valve




Load Sensing Valve



Four Circuit Protection Valve




Load Sensing Valve



Load Sensing Valve




Load Sensing Valve



Load Sensing Valve



Load Sensing Valve



Relay Valve



Load Sensing Valve



B1



B2

Relay Valve



A1



A2




A3

Relay Valve




Relay Valve




C1 C2 C3 C4

Relay Valve



B1 B2 B3 B4

Relay Emergency Valve



D1 D2 D3 D4

Relay Emergency Valve



E1



E2



E3



E4

Foot Brake Valve



A1




A2



A3

Relay Emergency Valve



F1



F2



F3



F4

Foot Brake Valve



B1



B2



B3



B4

Foot Brake Valve



C1



C2



C3



C4

Foot Brake Valve



E1



E2



E3



E4

Foot Brake Valve



D1



D2



D3



D4

Foot Brake Valve



F1



F2



F3



F4

Foot Brake Valve



G1



G2



G3



G4

Leveling Valve



A1



A2



A3




A4


Foot Brake Valve




H1




H2



H3



H4



H5

Leveling Valve



B1



B2



B3



B4

Leveling Valve



C1



C2



C3



C4

Leveling Valve



E1



E2

Leveling Valve



D1



D2



D3



D4

Leveling Valve



F1



F2

Leveling Valve



G1



G2



G3


Leveling Valve



J1



J2



J3

Leveling Valve




H1




H2


Leveling Valve




Leveling Valve



Leveling Valve




Leveling Valve



Pneumatic Suspension Level



Pneumatic Suspension Level



Pneumatic Suspension Level



Hand Brake Valve



Hand Brake Valve




Hand Brake Valve




Hand Brake Valve




Hand Brake Valve



Hand Brake Valve



Hand Brake Valve




Hand Brake Valve



Hand Brake Valve




Hand Brake Valve




Hand Brake Valve



Hand Brake Valve



HYVA Control Valve



Control Valve



A1



A2



A3



A4

Control Valve



C1



C2



C3



C4



C5

Control Valve



B1



B2



B3



B4

Control Valve



D1



D2



D3



D4



D5

Gearbox Valve



A1



A2



A3




A4

Gearbox Valve



C1



C2



C3



C4

Gearbox Valve



B1



B2



B3



B4

Gearbox Valve



D1



D2




D3



D4


Gearbox Valve




Trailer Control Valve



Gearbox Valve



Trailer Control Valve



Trailer Control Valve



C1



C2



C3



C4

Quick Release Valve



A1



A2



A3



A4

Trailer Control Valve



D1



D2



D3



D4

Quick Release Valve



B1



B2



B3



B4